


Adding a Panel Dimension


The Panel Dimension shows the number of Formwork components on a Wall. Handset Designer easily draws your Panel Dimension for you and places it on the right or left side of the Wall, depending on the Wall's direction. (For more information on right and left Wall directions, refer to [Working with Walls](#)).

To add a Panel Dimension:

1. Right-click the Wall
2. Select either the **Right Panel Dimension** or **Left Panel Dimension** from the dropdown menu that appears.



Handset Designer adds the Panel Dimension to your drawing, displaying the number of panels on the Wall. In the image below, an 8-foot Wall contains four Panels.



Note: Per convention, the Panel Dimension does not have any indicator of Panel heights or stackups.